



ThermPro
Indoor Humidity and Temperature
Monitor Instruction Manual

Model No.: TP157



English..... 2

V20210908 EN



1. Temperature
2. Display
3. Humidity
4. Comfort Level
5. °F / °C button

6. Hanging Hole
7. Magnet
8. Battery Compartment
9. Stand

1. Display: Displays the current humidity and temperature
2. °C/°F Button: Press once to change the temperature display to either °C or °F

3. Battery Compartment: Holds one 1 AAA battery to power the unit

4. 3 Icons Comfort Level: 😐 😊 😓

If humidity is below 30%: Dry 😐

If humidity is between 30% to 60% AND temperature is between 68°F-79°F (20°C-26°C): Comfort 😊

If humidity is above 60%: Wet 😓

If none of these conditions are met: No Icon

5. Totally wireless tabletop and magnet-mountable design

Before first use

1. Insert or Replace Battery: Insert one AAA battery in correct polarity (+) and (-) as indicated.
2. Do not immerse product body in water.
3. The humidity and temperature monitor is now ready to use.

Care of your humidity/temperature monitor

- Do not leave exposed to extreme high or low temperatures since this will damage electronic parts and plastics.

- Remove battery if stored for more than four months.

Specifications

1. Temperature range: -58 °F ~ 158°F (-50 °C ~ 70 °C).
2. Humidity range: 10% ~ 99%.
3. Comfort display: DRY, COMFORT, WET
4. Temperature display unit: °C/°F selectable
5. Temperature Resolution: 0.1 °C/°F
6. Humidity Resolution: 1%
7. Refresh rate: 10 seconds
8. Power supply: 1 X AAA 1.5V

Declaration of Conformity

Hereby, the manufacturer declares that this product complies with the basic requirements and applicable regulations of the EMC Directive 2014/30/EU. The complete declaration of conformity can be found at: <https://itronicsmall.com/eu-declaration-of-conformity/>

Disposal



Meaning of the "Dustbin" Symbol

- Protect our environment: do not dispose of electrical equipment in the domestic waste.

- Please return any electrical equipment that you will no longer use to the collection points provided for their disposal.
- This helps avoid the potential effects of incorrect disposal on the environment and human health.
- This will contribute to the recycling and other forms of reutilisation of electrical and electronic equipment.

- Information concerning where the equipment can be disposed of can be obtained from your local authority.



CAUTION: Batteries/rechargeable batteries must not be disposed of with household waste!

- The batteries must be removed from the appliance.
- Take spent batteries to the appropriate collection point or to a dealer.
- Your town or local authority can provide information about public collection points.

This symbol can be found on batteries/rechargeable batteries which contain hazardous:



- Pb = contains lead
- Cd = contains cadmium
- Hg = contains mercury
- Li = contains lithium

Limited one-year Warranty

ThermoPro warrants this product to be free of defects in parts, materials and workmanship for a period of one year, from date of purchase.

Should any repairs or servicing under this warranty be required, contact Customer Service by phone or email for instructions on how to pack and ship the product to ThermoPro.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Customer service

Telephone: 1-877-515-7797(USA & Canada only)
44-808-164-1683(UK)

Email: service@buythermopro.com

Hours: Weekdays 8:00 AM- 8:00 PM EST(USA
& Canada only)
Weekdays 1:00 PM - 12:00 PM CET(UK)