

ThermPro

FOOD THERMOMETER USER MANUAL

Model No. TP-02

Introduction

Thank you very much for choosing the pen type thermometer. It is good for measuring food temperature and normal contact temperature testing.

The meter is easy to operating. Just push out the probe cover and install the battery, touch the object and press the ON button to measure the temperature.

Please keep the thermometer at the place that children cannot touch to avoid getting hurt, as the probe is shape. Cover the probe after using.

Specifications

- Temperature range: $-50 \text{ --- } +300^{\circ}\text{C}$. ($-58 \text{ --- } +572^{\circ}\text{F}$)
- Resolution: $0.1^{\circ}\text{C}/^{\circ}\text{F}$.
- 0 minute auto shutdown.
- Power supply: 1.5V.

Functions and operation

Data Hold: Press the HOLD button to hold the temperature value when measuring. Press again to start new measuring.

$^{\circ}\text{C}$ and $^{\circ}\text{F}$ selecting: Press $^{\circ}\text{C} / ^{\circ}\text{F}$ button to select one of

them you need.

ON/OFF: Press the ON/OFF button to turn on the thermometer. Press again to shut off it.

MAX/MIN button: View the largest/ smallest.

LIMITED 90 DAYS WARRANTY

ThermoPro warrants this product to be free of defects in parts, materials and workmanship for a period of 90 days, from date of purchase.

Should any repairs or servicing under this warranty be required, contact Customer Service by phone or email for instructions on how to pack and ship the product to ThermoPro.

CUSTOMER SERVICE

Telephone: 1-877-515-7797

Email: service@buythermopro.com

Hours: Weekdays 9:00 AM- 5:00 PM EST

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.